

If you require further information or technical assistance with your electric fire

Call:
0300 111 0000

Email:
info@parkwaygreen.co.uk

Website:
www.parkwaygreen.co.uk

IMPORTANT:
PLEASE KEEP THIS GUIDE IN A SAFE PLACE FOR FUTURE REFERENCE

Caring for **your** fire



INFORMATION

Please keep this
guide in a safe place
for future reference



Congratulations on owning an Electric Fire from Be Modern



■ **Our range of stylish fires** has been designed to provide you with a clean and efficient heat source and provide years of safe hassle-free operation.

■ **To ensure this product provides you with maximum enjoyment** we have prepared this essential guide with valuable advice and guidance for you to follow.

■ **Please take time to read through this leaflet** and understand why looking after your fire will provide you with safe and continued operation.

WE RECOMMEND KEEPING THIS GUIDE IN A SAFE PLACE FOR FUTURE REFERENCE.



DO NOT X
Do not touch the fire with wet hands or in any way allow water to get into it.
Do not use the fire in immediate surroundings of bath, shower or swimming pool.

DO ✓
Always switch off the fire and allow to cool before doing any cleaning or maintenance.



DO NOT X
Do not place obstructions around the fire for instance curtains, furniture or clothing rails as this could cause overheating and a fire risk.

DO ✓
Keep the area around the fire free from obstacles to allow air to circulate freely around the fire.



DO NOT X
Do not allow a build up of animal hairs, dust and lint around the fire or allow the outlet grill to become blocked with a dust build up.

DO ✓
To remove accumulation of dust or fluff, the soft brush attachment of a vacuum cleaner should be used to clean the outlet grille of the fire located under the canopy and around the base of the fire.



DO NOT X
Do not use detergents, abrasive cleaning powder or polish on the metal body of the fire. Do not use aerosols or steam cleaners on or around the fire.

DO ✓
Always wipe over the outer surfaces of the fire with a dry soft cloth.



DO NOT X
Do not cover the fire. Do not use the fire to dry clothes etc. Do not place materials or garments on the fire or around the base of the fire.

DO ✓
Ensure that furniture, curtains or other combustible materials are positioned no closer than 1metre from the fire.



DO NOT X
Do not force items into any of the fire openings.

DO ✓
Always use a fireguard when young children and infirm persons can come into contact with the fire.
Supervise children to ensure they do not play with the appliance.

Your safety ...is our priority

Your electric fire is fitted with an automatic thermal cut out to reduce the risk of damage in the event of abnormal operation eg. if covered or jammed with foreign object or if there is a build up of lint and dust inside the fire. In the event of overheating the appliance will turn itself off.

1. Unplug the fire and wait 15 minutes to cool down. Then remove the cause of overheating. This may require the fire to be cleaned to remove a build up of dust or removal of an object.
2. Once the cause for overheating has been removed, switch on the fire to resume normal operation. *If the heater will not operate, disconnect and seek expert advice from our Technical Sales Team on 0300 111 0000*

Do not attempt to keep re-setting the safety device as this will cause potential damage and overheating leading to serious internal damage to the fire.